

Touch Free Emit på



EmiTag

Fäst EmiTag'n runt handleden som bilden visar. Vid stämpling i hög fart måste man hålla emiTag'n inom 20-50 cm från stämpingsenheten en kort stund till det röda lysdioden blinkar i EmiTag'n. Den röda lysdioden blinkar i 10 sekunder efter godkänd stämpel.



Obs! Det är viktigt att ni ser blinkningen. Detta är den enda bekräftelsen på godkänd stämpel!



Start

Håll EmiTag'n mot startenheten för att "nolla" EmiTag'n. Tiden startar när du lämnar enheten.

Mål

Sensorer på mållinjen stoppar tiden – ingen målstämpling.

Avläsning av EmiTag'n sker som vanligt efter målgång.

Touch Free Emit on



EmiTag

The EmiTag should be strapped around the wrist as shown on the picture. In speed the punching is performed by holding the EmiTag 20-50 cm from the control for a short moment. The LED light in the EmiTag will start flashing, and keeps flashing for 10 seconds after the punch.



NOTE! It is important to see this flashing, since this is the only feedback telling you that the punch is performed correctly!



START

- At start there will be Touch-Free Start PRO units.
- The time starts when the runner leaves the startunit

FINISH

Sensors at the finish line stops the time – no punching at the finish. The readout is after the finish line.